

RV-3029-C2

Development Board

DEVELOPMENT BOARD



RV-3029-62

Temperature Compensated Real Time Clock / Calendar Module

DATE: February 2011

Revision No.: 1.0

Headquarters:

Page 1/3 Micro Crystal AG Mühlestrasse 14 CH-2540 Grenchen Switzerland

Tel. +41 32 655 82 82
Fax +41 32 655 80 90
Internet www.microcrystal.ch
Email sales@microcrystal.ch

RV-3029-C2

RV-3029-C2


The RV-3029-C2 is soldered onto the Development Board.

Every pin is either accessible at test pins 1 - 10 or at the test vias situated around the device.

The following passive components are already soldered on the Board:

	J	and the contract of the contra
C1	10 nF	Decoupling capacitor between V _{SS} and V _{DD}
R1	330 Ώ	current limiting resistor for LED
LED	green	Supply, current consumption of the LED has to be considered
R2	10 kΏ	Pull-up resistor SCL to V _{DD}
R3	10 kΩ	Pull-up resistor SDA to V _{DD}
R4	10 kΏ	Pull-up resistor INT to V _{DD}
R5	10 kΩ	Protection resistor to prevent short-circuit between external CLKOE signal and Jumper.


DEVELOPMENT BOARD




Development Board

RV-3029-C2

SCHEMATICS



PINOUT RV-3029-C2



PIN DESCRIPTION

Symbol	Pin #	Description
V_{DD}	1	Positive supply voltage; positive or negative steps in supply voltage may affect oscillator performance, recommend 10 nF decoupling capacitor close to device
CLKOUT	2	Clock Output pin. CLKOUT or INT function can be selected.(Control_1; bit7; CLK/INT) CLKOUT output push-pull / INT function open-drain requiring pull-up resistor
NC	3	Not Connected; internally used for test, do not connect other signals then ground.
SCL	4	Serial Clock Input pin; requires pull-up resistor
SDA	5	Serial Data Input-Output pin; open-drain; requires pull-up resistor
V _{SS}	6	Ground
ĪNT	7	Interrupt Output pin; open-drain; active LOW
V _{BACKUP}	8	Backup Supply Voltage; tie to GND when not using backup supply voltage.
NC	9	Not Connected; internally used for test, do not connect other signals then ground.
CLKOE	10	CLKOUT enable/disable pin; enable is active HIGH; tie to GND when not using CLKOUT

Datasheet and Application-Manual are available for download under: www.microcrystal.com